L[®]

SNMP Web Pro

User Manual

Management Software for Uninterruptible Power Supply System

rev.01/19 71601999 – SNMP Web Pro User Manual

Table of Contents

Important Safety Warnings and Precautions	Error! Bookmark not defined.
FCC Statement	Error! Bookmark not defined.
Storage Precautions	Error! Bookmark not defined.
1. Installation and Setup	
Unpacking and Inspection	
Features of SNMP Web Card	4
Installing and Connecting the SNMP Web Card	5
2. Configuration	6
How to set a static IP on a Windows computer	6
2. Navigation Panel	
Information	8
UPS Setting	9
Control	
System Configuration	
Log	
Help	

Important Safety Warnings and Precautions

Storage Precautions

If the card must be stored prior to installation; storage must be in a dry place. The admissible storage temperature range is from 10° C to $+70^{\circ}$ C.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1. Installation and Setup

NOTE: Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. Please keep the original package in a safe place for future use.

Unpacking and Inspection

Unpack your products and inspect the contents. The contents should include the following supplied components and hardware.



SNMP Web Card



SNMP Web Pro Quick Start Guide

- SNMP Web Card
- SNMP Web Pro Quick Start Guide

Required software can be downloaded at **www.legrand.us/upsdownloads**

NOTE: Before installation, inspect all supplied components and hardware to ensure nothing was damaged during transportation. If you notice any damaged or missing parts, notify the carrier and purchasing agent immediately. Please keep the original package in a safe place for future use.

Features of SNMP Web Card

- Open monitor via Web Browser
- Offer SNMP MIB to monitor UPS status
- Automatically detect and exchange 10M/100M Fast Ethernet
- Support wake-on-LAN function
- Supported protocol include but are not limited to TCP/IP, UDP, SNMP, SMTP, SNTP, HTTP, HTTPS, SSL, SSH, IPV4/IPV6, DHCP.
- Integration with Shutdown Wizard can prevent data loss from power outage and safely shut down systems.
- Event log storage of 200,000+ threads, including UPS warnings, faults, EMD warnings, and operation data logs from web users or ViewPower Pro users. Event logs will be stored safely if power failure occurs.
- Support daily reports for event log and data log
- Scheduled UPS on/off and battery test
- Support Environmental Monitoring (EMD) and SMS sending
- Equipped with real-time clock to record log with date and keep running up to 7 days without power connected.



Label Descriptions:

- 1. Ethernet port (10/100Base-T)
- 2. Sensor/data transmission port (EMD port)
- 3. SNMP card connector: connects to UPS slot
- 4. Ethernet port status LEDs
- 5. Jumper setting to restore default setting

Ethernet port status LEDs:

100M LED (Green)	On	Port is operating at 100Mb/s
	Off	Current web bandwidth is 10Mb/s
Link status LED (Yellow)	Flash	Link Active
	Off	Card is not connected to the network

Pin assignment for Jumper:

Pin #	Status	Description
Pin 1 & Pin 2	Closed	Normal operation
Pin 2 & Pin 3	Closed	After re-connecting utility, the IP address of SNMP web card and password will restore to default setting.
		Default static IP address: (192.168.102.230)
		Default password: 12345678

NOTE: After setting is restored to default, be sure to change the jumper setting to connect Pin 1 and Pin 2 for normal operation.

Installing and Connecting the SNMP Web Card

Step 1: Remove the cover of intelligent slot on the back panel of UPS and retain the screws.



Step 2: Slide the card into the open intelligent slot and secure with the screws from step 1.



Step 3: Plug one end of the Ethernet cable to the Ethernet port (RJ-45) on the SNMP Web Card and plug the other end of the Ethernet cable to router.

Note: When connecting to the router, connect to the same LAN as the computer with the SNMP Web Manager software installed.



2. Configuration

Connect computer to the router or connect directly to the SNMP Web Card via an Ethernet cable.

How to set a static IP on a Windows computer

- 1. Click **Start Menu** > **Control Panel** > **Network and Sharing Center**. (For Windows 8 and higher, search for and open Control Panel and select Network and Internet).
- 2. In the left panel, click **Change adapter settings**.



3. Right-click on Local Area Connection and click on Properties.



4. Select Internet Protocol Version 4 (TCP/IPv4) and click on Properties.

Local Area Connection Properties
Networking Sharing
Connect using:
Intel(R) PRO/100 VE Network Connection
Configure
This connection uses the following items:
QoS Packet Scheduler
File and Printer Sharing for Microsoft Networks
General NDIS Protocol Driver
Internet Protocol Version 6 (TCP/IPv6)
Internet Protocol Version 4 (TCP/IPV41)
Link-Layer Topology Discovery Mappen //O Diver
Install Uninstall Properties
Description
Transmission Control Protocol/Internet Protocol. The default wide area network protocol that provides communication across diverse interconnected networks.
OK Cancel

- 5. Select Use the following IP address and enter the IP address, Subnet mask, Default gateway
 - a. Enter the following in the IP address: 192.168.102.XXX (XXX must be replaced with the network range).
 - b. The Subnet mask should populate 255.255.255.0 (If it does not populate, manually enter 255.255.255.0 in the Subnet mask).
 - c. The Default gateway should populate 192.168.102.1 (If it does not populate, manually enter 192.168.102.1 in the Default gateway).

ou can get IP settings assigner is capability. Otherwise, you r r the appropriate IP settings.	d autom need to	aticall ask y	y if y	you	r net vork	adr	rk supp ninistra	ort: tor
Obtain an IP address auto	matical	у						
IP address:	a.	192	. 16	8.	102		XX	
Subnet mask:	b.	255	. 25	5.	255	•	0	
Default gateway:	с.	192	. 16	8	102	2.	1	
 Obtain DNS server address Use the following DNS server Preferred DNS server: 	s autom ver addi	esses 8	y : . 8	3.	8		8	
Alternate DNS server:		4	. 2	2 .	2		1	
Validate settings upon exi	t					A	d <u>v</u> ance	d

6. Click **OK** and close the Internet Protocol Version 4 (TCP/IPv4) Properties.

- 7. Open a web browser to access web server directly.
- 8. Enter default IP address 192.168.102.230 in the address bar of the web browser. This will bring up the main screen and login section on the Legrand SNMP Web Pro page.
- 9. Click **Login** and enter the default password 12345678.

SNMP web pro x → C ① Not secure	192,168,102,230	e – a e Q
1 legrand	SNMP Web Pro 1.1	Status Login Guest
Information Status Basic information UPS setting Parameters setting	UPS information UPS mode: Line Mode Auto reboot: enabled ECO Mode: disabled Bypass not allowed: disabled UPS warning:	UPS temp.: 21.2 °C Converter mode: disabled Bypass when UPS is off: disabled Fault type:
Control Real-time control System configuration	Input information Input voltage: 116.1 V	Input frequency: 60.0 Hz
Web E-mail SMS	Output information Output voltage: 120.2 V Output current: 0.0 A	Output frequency: 60.0 Hz Load level: 0 %
Upload Wake on LAN Shutdown	Battery information Battery voltage: 27.4 V Remaining backup time: 362 Min	Battery capacity: 97 %
Event action Scheduled System time SNMP configuration	EMD information EMD temp.: °C Alarm1: -	Humidity: % Alarm2: -
Data log Data log <u>Help</u> Serial Port Debug Firmware Upgrade		

Navigation Panel: Information

Select **Information** > **Status**. This screen displays real-time monitored UPS data including input, output, UPS and battery information in a table format.

SNMP web pro 🗙 🗙		θ - σ ×
← → C ① Not secure	192.168.102.230	~ Q ☆ :
🛿 legrand	SNMP Web Pro 1.1	Status Logout Administrator
Information Data Basic information UPS setting Parameters setting	UPS information UPS mode: Line Mode Auto reboot: enabled ECO Mode: disabled Bypass not allowed: disabled UPS warning:	UPS temp.: 21.0 °C Converter mode: disabled Bypass when UPS is off disabled Fault type:
Control Real-time control System configuration	Input information Input voltage: 116.1 V	Input frequency: 60.0 Hz
Web E-mail SMS	Output information Output voltage: 119.8 V Output current: 0.0 A	Output frequency: 60.0 Hz Load level: 0 %
Upload Wake on LAN Shutdown	Battery information Battery voltage: 27.4 V Remaining backup time: 363 Min	Battery capacity: 97 %
Event action. Scheduled System time SNMP configuration	EMD information EMD temp.: °C Alarm1: -	Humidity: % Alarm2: -
Log Evant log Data log Help Serial Port Debug Firmware Upgrade		

Select **Information** > **Basic information**. This screen displays UPS basic information, battery information and UPS rated information.



UPS setting

Select **UPS setting** > **Parameters setting**. Parameter setting includes backup time setting for P1 (battery mode), battery numbers setting, voltage and frequency range setting for bypass mode and voltage range setting for ECO mode.

C O Not secure	192.168.102.230	6 Q
1 legrand	SNMP Web Pro 1.1	Parameters setting Logout Administrator
Information	Alarm control: Enable Disable Apply	Advanced ECO mode:
Status	Alarm at bypass mode: Enable Disable Apply	Green power function: O Enable O Disab
Basic information	Alarm at battery mode: Enable Disable Apply	Cold start: Enable Disab
UPS setting	Auto reboot: Enable Disable Apply	Bypass not allowed: O Enable O Disab
Parameters setting	Bypass when UPS is off: Enable Disable Apply	Battery deep-discharge protection: Enable Disab
Control	Converter mode: © Enable ® Disable Apply	Site fault detection: Enable Disable
Real-time control	ECO mode: © Enable ® Disable Apply	P1 programmable outlet control: © Enable ® Disab
System configuration	101210000	
Web	Outlet setting	Battery numbers setting
E-mail	Backup time for P1(battery mode): 999 Min Apply	Numbers in parallel: 1 Ap
SMS		
Upload	Voltage and frequency range for bypass mode	Voltage range for ECO mode
Wake on LAN	Max. voltage: 132 V Apply	Max. voltage: 126 V
Shutdown	Min. voltage: 85 V Apply	Min. voltage: 114 V
Event action	Max. frequency: 63 Hz Apply	
Scheduled	Min. frequency: 57 Hz Apply	
SNN/ID configuration	1417	
Log		
Event los		
Data log		
Help		
Serial Port Debug		
Firmware Upgrade		
11.372		

Note: Different UPSs may access different parameter settings.

Modifying Parameters setting

- 1. Select the functions by clicking **Enable** or **Disable** button. Change numbers by clicking and modifying directly in the number column.
- 2. Click **Apply** button to save the settings. Each function setting is saved by clicking **Apply** button in each section.
- 3. Click **Default** button to recover the default settings.

	192.168.102.230	० न् ध्
llegrand	SNMP Web Pro 1.1	Parameters setting Logout Administrator
Information	Alarm control: Senable Disable Apply	Advanced ECO mode:
Status	Alarm at bypass mode: Enable Disable Apply	Green power function: O Enable O Disat
Basic information	Alarm at battery mode: Enable Disable Apply	Cold start: Enable Disat
UPS setting	Auto reboot: Enable Disable Apply	Bypass not allowed: Enable Disat
Parameters setting	Bypass when UPS is off: O Enable O Disable Apply	Battery deep-discharge protection: Enable Disat
Control	Converter mode: Enable Disable Apply	Site fault detection: Enable Disat
Real-time control	ECO mode: @ Enable @ Disable Apply	PI programmable outlet control: O Enable @ Disat
System configuration	Outlat action	Potton overlag
Web	Dealman since for D1(hottom models 000	Numbers in normalistication
E-mail	Markup time for F1(battery mode): 999 Min Apply	Numbers in parallel: 1
SMS	Voltage and frequency source for hypers made	
Upicad White an LAN	Man and irequency range for oypass mode	Voltage range for ECO mode
Shutdown	Max. voltage: 152 V Apply	Max. voltage: 126 V
Event action	Min. voltage: 85 V Apply	Min. voltage: 114 V
Scheduled	Max. frequency: 63 Hz Apply	
System time	Min. frequency: 57 Hz Apply	
SNMP configuration		
Log		
Event log		
Data log		
Help		
Serial Port Debug		
Firmware Upgrade		

Note: Any functions which are not supported by the UPS will not be able to access Parameters setting.

Parameter Descriptions

- Alarm control: If enabled, UPS alarm will be activated.
- Alarm at bypass mode: If enabled, UPS alarms when it's working at bypass mode.
- Alarm at battery mode: If disabled, UPS will not alarm when it's working at battery mode.
- Auto reboot: If enabled, UPS will auto recover when AC is recovering.
- Bypass when UPS is off: If enabled, AC will directly provide power to connected devices when UPS is off.
- Converter mode: If enabled, the UPS will operate in converter mode.
- **ECO mode:** If enabled, the UPS will operate in ECO mode when input voltage is within acceptable range.
- Cold start: If disabled, the UPS can be turned on only when AC is connected to UPS.
- **Bypass not allowed:** If enabled, the UPS will not transfer to bypass mode under any conditions. If disabled, the UPS will be allowed to transfer to bypass mode according to the UPS internal setting.
- **Battery deep-discharge protection:** If enabled, the monitored UPS shuts down in accordance with the condition and load on the battery to protect battery.
- Site fault detection: If enabled, the monitored UPS will beep when the neutral input and hot wires are reversed.
- **P1 programmable outlet control:** If enabled when UPS is running at battery mode it will cut off P1 outlets after backup setting time arrives. If disabled, UPS will provide continuous power to P1 outlets until the battery runs out of power.
- **Outlet setting:** Users can set limited backup time for P1 outlets when UPS is on battery mode.
- **Battery numbers setting:** Set battery numbers in parallel.
- Voltage and frequency range for bypass mode: Set acceptable voltage and frequency range in bypass mode
- **Maximum and minimum voltage:** When UPS is on bypass mode and input voltage is out of setting range, UPS will enter battery mode.
- **Maximum and minimum frequency:** When UPS is on bypass mode and input frequency is out of setting range, UPS will enter battery mode.

• Voltage range for ECO mode: Set acceptable voltage range for ECO mode.

Control

Select **Control** > **Real-time control**.

🖉 SNMP web pro 🗙 🗙				Θ	- 0 ×
\leftrightarrow \rightarrow C \bigcirc Not secure	192.168.102.230				on Q ☆ :
🛛 legrand	SNMP Web Pro 1.1		Real-time control	Logout Administrator	
Information Status Basic information UPS setting Parameters setting Control East-time accentrol System confluence Web E-mail SMS Upload Upload Upload Upload Scheduled System time Scheduled System time Scheduled System time Scheduled System time Scheduled System time Scheduled System time Scheduled System time	Alarm control UPS turn on/off On Off Off UPS On/Off control Battery self-test 10-second self-test Deep discharge test Minute self-test: 1 Min(s). Start Car	lay 30 Sec. turn on delay 30	Sec. Apply		

The UPS has real-time control by executing the following operations:

- UPS turn On/Off: Click On to turn on the UPS and Off to turn off the UPS immediately.
- **Battery self-test:** There are three types of battery self-tests:
 - 1. 10-second self-test
 - 2. Deep discharge test
 - 3. Minute self-test (self-defined)

Simply click the **Start** button next to each test. The self-tests will begin immediately.

System configuration

Select **System configuration > Web.**

To configure the authority to access SNMP Web Pro, please enter access ID and password in each column. There is no limitation to access control in default setting. It is also allowed for http and https modification. The default setting is 80 for http and 443 for https. If any modification is necessary for adding web users, deleting web users, or port re-configuration, click **Restart Web Server** button to restart the web server and activate all modifications.

SNMP web pro 🗙							0 – 0 X
← → C ③ Not secure	192.168.102.230						∽ Q ☆ :
🛛 legrand	SNMP Web Pro 1.1				Wet) Logout Administrator	
Information Status Basic information UPS setting	* : Restart the web server to take effect Web Server Configure		Http Port 🖲 : Https Port:	80 443	Apply Apply		
Parameters setting <u>Control</u> Real-time control <u>System configuration</u> Web	User Account	User Name			Password	Permission Read	Operation
E-mail SMS Upload Wake on LAN Shutdown Event action Scheduled System time SNMP configuration							Restart Web Server
Log Event log Data log Help Serial Port Debug Firmware Upgrade							

E-mail

Select **System configuration > E-mail.**

E-mail notifications can be setup through **SMTP server**. E-mail configuration requires the SMTP information, e-mail account, and associated password. The e-mail account should be configured to allow for SMTP/POP3 forwarding.

SNMP web pro 🗙 🗙							θ	-	٥	×
← → C ① Not secure	192.168. <mark>1</mark> 02.230							07	Q 🕁	:
Lī legrand	SNMP Web Pro 1.1				E-mail !	Logout Administrator				
Information	SMTP server:	smtp.test.com			Receive J	L:	Apply	Delete		
Status	Security Type:	◎ None ● SSL ◎ TLS			Receive 2	2:	Apply	Delete		
Basic information	Port:	465			Receive ?	3:	Apply	Delete		
UPS setting	Send from:				Receive 4	k:	Apply	Delete		
Parameters setting	User name:	test			Receive !	5	Apply	Delete		
Control	1000	Need Auth			Receive (i.	Annh	Delete		
Real-time control	Password:				Receive (,. 1:	Annh	Delete		
System configuration	Note: A	After apply, you can click "Test" b	button to send a test message.		Receive		Apply	Delete		
F.mail	L	Apply Test		- Contract	Receive a	5:	Apply	Delete		
SMS				Passwo	ord get back Emai	l:	Apply	Delete		
Upload				Recipi	ient's Email Addre	es (for Daily Report)				
Wake on LAN				Account 1:	cht 5 Einan Muit	Anniv Delete				
Shutdown				Account 2:		Apply Delete				
Event action				Account 2:	00.00	Apply Delete				
Scheduled			Send Email for Daily F	teport (hh:mm): at	00:00					
System time			Send Email when Data Log o	verflows (30M):						
SNMP configuration				Apply	2					
Log					-					
Event log										
Data log										
Secil Bet Deber										
Firmurare Unerade										
i ninwate Opgrade										

- 1. To configure E-mail settings, fill out the SMTP server and security information.
 - Enter SMTP server
 - Choose Security Type (supported encryption from SMTP server)
 - Enter SMTP Port
 - Enter sender's E-mail address in Send from
 - Enter User name and Password
 - Click checkbox of **Need Auth** for password verify
- 2. Enter e-mail accounts in **Receive** fields. Then, click **Apply** to add into receivers list. If you wish to remove an e-mail account, click the delete button next to the field.
- 3. Click **Apply** to save the changes. The **Test** button can be used to send a test e-mail to all email recipients to confirm correct operation. When the test e-mails are successfully sent to specific recipients, it will pop up a successful message on operated PC. Otherwise, it will pop up a failure dialog to indicate there is an error for parameter setting.
- 4. For the Daily Report, setup recipient's e-mail and check the box Send Email for Daily Report (hh:mm) to choose a specific time. Then click the Apply button to set up this action. You can also configure who will receive alarm e-mails when event log exceeds 100 or data log exceeds 50 records. Please click checkbox of selections.

SMS

Select System configuration > SMS.

Sending SMS By Server

It is required to have service software available such as ViewPower Pro. In the event of an alarm condition occurring, a message about UPS status will be sent to the specified users via mobile phone.

Sending SMS By Serial Port

The sensor/data transmission port (EMD port) is used for data transmission to send SMS without any service software. Please configure Baud rate of GSM Modem as 9600 and then connect data transmission port (\Box) of SNMP web port card to GSM Modem with a RJ11 to DB9 cable. Please refer to detailed wiring.



DB-9

SNMP web pro X			θ – σ ×
← → C ① Not secure	192.168.102.230		~ Q ☆ :
Lī legrand	SNMP Web Pro 1.1	SMS Logout Administrator	
Information Status Basic information UPS setting Parameters setting Real-time control System configuration We Earnil SMS Upload Wake on LAN Shutdown Event action Schedulad System time SNMP configuration Log Event log Data log Help Serial Port Debug	Send SMS By: • Sarvar • Serial Port SMS maximum length 10 U222 Port: 41222 Account name: Password: •••••• Note1: After apply, you can click "Test" button to send a test message. Note2: If send SMS by serial port,EMD function will be disabled. Apply Test	Receive 1:Apply:DeleteReceive 2:Apply:DeleteReceive 3:Apply:DeleteReceive 4:Apply:DeleteReceive 5:Apply:DeleteReceive 6:Apply:DeleteReceive 7:Apply:DeleteReceive 8:Apply:Delete	

Wake on LAN

Select System configuration > Wake on LAN.

Remotely wake on specific local area network PCs when these PCs are supported to **Wake on LAN** (WOL) via a magic packet.

🖌 🐇 SNMP web pro 🛛 🗙 🔪								Θ	_	٥	×
← → C ③ Not secure	192.168.102.230								07	0,☆	:
Lī legrand	SNMP Web Pro	1.1			,	Wake on LAN	Logout Administrator	8			, , ,
Information	MAC address 01:	00-00-00-00-00	Apply I)elete							
Status	MAC address 02:	00-00-00-00-00	Apply I)elete							
Basic information	MAC address 03:	00-00-00-00-00	Apply I	Delete							
UPS setting	MAC address 04:	00-00-00-00-00	Apply I	Delete							
Control	MAC address 05:	00-00-00-00-00	Apply I	Delete							
Real-time control	MAC address 06:	00-00-00-00-00	Apply)elete							
System configuration	MAC address 07:	00-00-00-00-00	Apply I)elete							
Web	MAC address 08:	00-00-00-00-00	Apply I)elete							
E-mail	MAC address 09:	00-00-00-00-00	Apply I	Delete							
SMS	MAC address 10:	00-00-00-00-00	Apply I	Delete							
Wake on LAN	MAC address 11:	00-00-00-00-00	Apply I)elete							
Shutdown	MAC address 12:	00-00-00-00-00	Apply I)elete							
Event action	MAC address 13:	00-00-00-00-00	Apply I)elete							
Scheduled	MAC address 14:	00-00-00-00-00	Apply I	Delete							
System time	MAC address 15:	00-00-00-00-00	Apply I	Delete							
Log	MAC address 16:	00-00-00-00-00	Apply I)elete							
Event log	MAC address 17:	00-00-00-00-00	Apply)elete							
Data log	MAC address 18:	00-00-00-00-00	Apply)elete							
Help	MAC address 19:	00-00-00-00-00	Apply I)elete							
Serial Port Debug	MAC address 20:	00-00-00-00-00	Apply I)elete							
Firmware Upgrade	MAC address 21:	00-00-00-00-00	Apply I	Delete							
	MAC address 22:	00-00-00-00-00	Apply)elete							
	(MAC address form	nat: 01-1F-C6-C7-E0-08)									

Remote PC control will occur after MAC addresses of remote PCs have been entered into the address columns.

Note: The network card and mainboard of the computer need to support the wake-up function for remote PCs to implement this function.

Shutdown

Select System configuration > Shutdown.

Remotely shut down specific PCs with Shutdown Wizard.

SNMP web pro x								Θ	-	٥	×		
← → C ① Not secure 1	92.168.102.230	0									0-7	Q 🕁	:
												. , ,) •
Degrand	CNIMD W.L	D 1 1					Churchdower						
Litegiana	SINIMIT WED	FT0 1.1					Shudown	Logout	Administrato				
	New centre list hole												
Information	four script list beit	ow.											
Status	No script availabl	le!											
Basic information													
UPS setting	select No file se	elected!											
Parameters setting	*You can enter scri	ipt name in command field	d if you want to ex	ecute it by	SSH.								
Control													
Real-time control	"If you are using th	he ShutdownWizard 1.02 a	and above please c	heck AES	encryption.								
System configuration			AFS	SSH									
Web		IP address	encryption sh	utdown	User name	Password	Command						
E-mail	01: 0.0	.0.0			root	•••••	halt	Apply	Delete 01				
SMS	02: 0.0	.0.0			root	•••••	halt	Apply	Delete 02				
Upicad	03: 0.0	.0.0			root	•••••	halt	Apply	Delete 03				
Wake on LAN Shutduur	04: 0.0	.0.0			root	******	halt	Apply	Delete 04				
Shutaown	05: 0.0	.0.0			root	•••••	halt	Apply	Delete 05				
Sebadalad	06: 0.0.	.0.0			root	*******	halt	Apply	Delete 06				
Scheduled	07: 0.0.	.0.0			root	*******	halt	Apply	Delete 07				
System time	08: 0.0	.0.0			root	*******	halt	Apply	Delete 08				
Log	09: 0.0.	.0.0			root	•••••	halt	Apply	Delete 09				
<u>Log</u> Roomt lan	10: 0.0.	.0.0			root	•••••	halt	Apply	Delete 10				
Dete los	11: 0.0.	.0.0			root	*******	halt	Apply	Delete 11				
Data log	12: 0.0.	.0.0			root	******	halt	Apply	Delete 12				
Heip	13: 0.0.	.0.0			root	******	halt	Apply	Delete 13				
Senal Port Debug	14: 0.0.	.0.0			root	******	halt	Apply	Delete 14				
r irmware Upgrade	15: 0.0.	.0.0			root	•••••	halt	Apply	Delete 15				
	16: 0.0.	.0.0			root	******	halt	Apply	Delete 16				
	17: 0.0.	.0.0			root	*******	halt	Apply	Delete 17				
	18: 00	0.0			root	*******	halt	Apply	Delete 18				

Event action

Select **System configuration > Event action.**

SNMP web pro 🛛 🗙				θ		٥	×
- > C O Not secure	192.168.102.230				0-	Q ☆	
Lī legrand	SNMP Web Pro 1.1	Event action	Logout Administrator				
Information Status Basic information UPS setting Parameters setting Control Real-time control System configuration Web E-mail SMS Upload Wake on LAN Control Schednaled System time StMP configuration Schednaled System time StMP configuration Configuration Configuration Status StMP configuration Status StMP configuration Configuration Status StMP configuration Status StMP configuration Configuration Status StMP configuration Configuration Status StMP configuration Status StMP configuration Configuration Status StMP configuration Status StMP configuration StMP configuration	 Shutdown the PC while battery mode. Shutdown PC: * ghr 1800 See & battery capacity is less that 20 %. The needed for shutting down the PC 120 Sec. The FC should: * Shutdown * Ge to step Also power off the UPS after shutting down the PC. Apply Shutdown the PC while low battery. Apply Shutdown the PC while low battery. Apply Sead E-mail while any UPS's event occurs. Apply Shutdown the PC while temperature upper limit. 55 °C (Apply) EMD alarming temperature upper limit 100.0 % (Apply) EMD alarming temperature upper limit 100.0 % (Apply) EMD alarm reset (Apply) Data record interval 60 Sec. (Apply) 						

- **Shutdown the PC while in battery mode:** When selected and integrated with the Shutdown Wizard, local PC will shut down when the UPS initiates battery mode.
- Time needed for shutting down the PC: Enter the delay time to shut down the operating system.
- The PC should:
 - 1. Shutdown: The system will shut down when selecting Shutdown and clicking Apply.

- 2. Go to sleep: The system will be suspended instead of a normal shutdown when selecting Go to sleep and clicking Apply. This function is only supported by Windows 2000 or higher with supported hardware.
- Also power off the UPS after shutting down the PC: If selected, the monitored UPS will turn off after local system shuts down. The UPS shutdown time will be later than complete system shutdown time. Users can choose to shut down the system without shutting down the UPS.
- Shutdown the PC while low battery: Select and click Apply for the local PC to shut down when the monitored UPS battery is running low.
- Wake on LAN while AC recovery: Select and click Apply for the local PC will wake on LAN while in AC recovery.
- Send E-mail while any UPS's event occurs: Select and click Apply to receive a notification E-mail when any event occurs on the local UPS.
- Send SMS while any UPS's event occurs: Select and click Apply to receive a message in the event of an alarm. A message about the UPS status will be sent to the specified user's mobile phone.

Scheduled

Select **System configuration > Scheduled.**

SNMP web pro 🗙						Θ	— (7	×
← → C ① Not secure	192.168.102.230						0- G	1 \$:
Lī legrand	SNMP Web Pro 1.1			Schedule	l Logout Administrator				
Information Status Basic information UPS setting Parameters setting Control Real-time control System configuration Web E-mail Upload Wake on LAN Shufdown E-mail Upload Wake on LAN Shufdown E-mail Scheduled System time Scheduled System time Scheduled System time Scheduled System time Scheduled System time	Battery te Frequency: © Once © Daily © Weekly Date(yyyyimmide): 2014402' Start time(th:mm): 00:00 Method: © 101402' Start time(th:mm): 00:00 Method: © 101402' Start time(th:mm): 00:00 Method: © 101402' Start time(th:mm): 00:00 Method: © 101402' Power off at: 2014-01-01 © Make PC ahub Power of at: 2014-01-01 © Make PC ahub © Weekly Power of at: 2014-01-01 © Make PC ahub © Weekly Power of at: 2014-01-01 © Make PC ahub Power of at: 2014-01-01 © Make PC ahub Pow	st scheduled r 12 md self-test t 1 Min scharge test scharge test (yyyy/mm/dd) 00.00 after UPS power on Apply Apply	(bh:mm) c off (bh:mm)						

- **Battery test scheduled:** Scheduled battery self-test can be executed once, daily, weekly, or monthly. Users can select UPS and time parameters. It is recommended to set only one action at a time. If multiple actions have been applied at the same time, some of these actions may be ignored. Any action will be ignored when the action is not supported by the UPS.
- **UPS On/Off schedule:** Scheduled UPS on/off can be executed once, daily, or weekly. Users can select UPS and time parameters. It is recommended to set only one action at a time. If multiple actions have been applied at the same time, some of these actions may be ignored. Any action will be ignored when the action is not supported by the UPS.

System time

Select System configuration > System time.



- Automatic time correction interval
- **Time server:** The SNTP server IP address or domain name.
- Time Zone (Relative to GMT): It's measured to relative to GMT.
- System Time (mm/dd/yyyy hh:mm:ss): Set up SNMP web local host time.
- Auto Restart System for Every (0: Disable): XX Minute(s) and click Apply button.
- Manual Restart System After 30 Seconds: When the Apply button is checked, the SNMP will restart after 30 seconds.

SNMP configuration

Select System configuration > SNMP configuration.

Settings of the SNMP web pro basic information include IP address, password, trap IP address, SNMP UDP port, add/delete snmpv3 user account and the ability to restore the factory settings.

Note: Some modifications require the SNMP server to be restarted to become effective.



- **IP address:** There are two methods to obtain IP address
 - 1. Automatically obtain IP address (DHCP, default)
 - 2. Manually configure IP address

The system will automatically obtain default IP addresses. If there are none provided by the LAN, the default IP will display as "192.168.102.230", Net mask as "255.255.255.0" and default gateway as "0.0.0.0".

- **Password:** Modify the password. The length of the password must be between 8 to 15 digits.
- Trap IP address: The SNMP device could provide 12 static trap addresses.
- **SNMP server configuration:** You may change the SNMP port and trap port. You also can add SNMPV3 users by clicking the **Add** button. A screen will pop up to setup user settings, security level, and permission level.
- Restore the factory settings

Note: The system will default the IP addresses and the default Password is 12345678.

Log

Event Log

Select Log > Event log.

The event log page shows past events and can store over 200,000 threads. The event logs can be saved as a .csv file. The event log includes UPS warnings, fault info, and UPS operation logs from web users and ViewPower Pro users. All logs are recorded in the flash memory of the web card by month. The event logs are safely stored in the event of power failure."

SNMP web pro 🗙			Θ	– 0 ×
← → C ③ Not secure	192.168.102.230			•• ९ ☆ :
🛛 legrand	SNMP Web Pro 1.1	Event log Logout Ad	lministrator	
Information	01_2010.csv ▼ Apply Delete			
Status Basic information UPS setting Tarameters setting Control Real-time control System configuration Web E-mail SMS Upload Walke on LAN Shuddovn Event action Schednaled System time SNMP configuration Up of Data log Data log Serial Port Debug Firmivare Upgrade	Time 01/01/2010 00:00.33 01/01/2010 00:03:44 01/01/2010 00:21:623 01/01/2010 00:21:623 01/01/2010 02:16:27	Levent name F Connect to time server error N Line Mode N Dattery self-test failure N Line Mode N Table of the server error N	Yent source SNTP SNTP ICU Polling ICU Polling SNTP ICU Polling CU Polling	Client IP

Data log

Select Log > Data log.

The data log page will list all recorded data and can store over 200,000 threads. The data logs can be saved as a .csv file. The data logs are safely stored in the event of power failure.

💊 SNMP web pro 🗙 🗸						Θ -	σ×
\leftarrow \rightarrow C (i) Not secure	192.168.102.230					0	• ♀ ☆ ∶
L7 legrand	SNMP Web Pro 1.1			Data log	Logout Admini	strator	
Information	01_01_2010.csv V Apply Delete			12245			
Status	Time	Input voltage(V)	Output voltage(V)	Output frequency(Hz)	Load(%)	Battery voltage(V)	Temp.(°C)
Basic information	01/01/2010 03:28:07	116.5	119.6	60.0	0	27.3	21.1
UPS setting	01/01/2010 03:29:07	116.7	119.7	60.0	0	27.3	21.2
Parameters setting	01/01/2010 03:30:07	116.4	119.4	60.0	0	27.4	21.4
r at ameters setting	01/01/2010 03:31:07	116.2	119.5	60.0	0	27.4	21.5
Control	01/01/2010 03:32:07	116.6	119.3	59.9	0	27.3	21.8
Real-time control	01/01/2010 03:33:07	116.7	119.9	60.0	0	27.4	21.8
System configuration	01/01/2010 03:34:07	110.0	119.5	60.0	0	27.4	22.0
Wab	01/01/2010 03:35:08	116.2	119.5	60.0	0	27.4	21.8
Web	01/01/2010 03:30:08	116.4	119.9	60.0	0	27.4	21.7
E-mail	01/01/2010 03:38:08	116.2	120.1	60.0	0	27.4	21.5
SMS	01/01/2010 03:39:08	116.0	119.9	60.0	0	27.4	21.4
Upload	01/01/2010 03:40:08	116.1	119.8	60.0	0	27.4	21.1
Wake on LAN	01/01/2010 03:41:09	116.1	119.5	60.0	0	27.3	20.8
Shutdown	01/01/2010 03:42:09	115.8	119.6	60.0	0	27.3	20.7
Erent a stiller	01/01/2010 03:43:09	116.2	120.2	60.0	0	27.3	20.5
Event action	01/01/2010 03:44:09	116.2	119.6	60.0	0	27.4	20.5
Ocheduled	01/01/2010 03:45:09	116.4	119.4	60.0	0	27.3	20.6
System time	01/01/2010 03:46:09	115.9	120.2	60.0	0	27.4	20.7
SNMP configuration	01/01/2010 03:47:09	116.6	120.3	60.0	0	27.4	20.8
Log	01/01/2010 03:48:10	116.5	119.5	60.0	0	27.3	21.1
 72	01/01/2010 03:49:10	116.2	119.5	60.0	0	27.3	21.2
Event log				12340			
Data log							Save as
Help							
Serial Port Debug							
Firmwara Ungrada							
a minimare Opgrade							

Help

Serial Port Debug

Select Help > Serial Port Debug.

Test communication condition between SNMP card and device. Enter the RS232 command supported by the UPS and click send to see return value of UPS. This function is generally used for fault diagnosis.

SNMP web pro 🗙 🗙			Θ	- 0 ×
\leftrightarrow \rightarrow C \bigcirc Not secure	192.168.102.230			• Q☆:
🛱 legrand	SNMP Web Pro 1.1	Serial Port Debug	Logout Administrator	
Information Status Basic information UPS setting Parameters setting Control Read-time control System configuration Web E-mail Upload Wake on LAN Studiovan Upload Wake on LAN Studiovan E-vent action Scheduled System time StMP configuration Log Event log Data log Event log Data log Event log Data log	Send content: Output window:	Send Clear		

Firmware Upgrade Select Help > Firmware Upgrade.

Check for the latest firmware updates. Click Select to download the available update.

