

Catalog Number • Numéro de Catalogue • Número de Catálogo: WBT900-IP

Country of Origin: Made in China • Pays d'origine: Fabriqué en Chine • País de origen: Hecho en China



SPECIFICATIONS

Volts 12-24 VAC or VDC
 UL Standards Tested UL 2043 plenum rated
 902-928MHz Direct Sequence Spread Spectrum (DSSS)
 Synchronous point-to-multipoint communication
 Special Features
 Includes unity gain antenna
 AES 128-bit encrypted payload protection

DESCRIPTION AND OPERATION

The WBT900-IP is designed to transport BACnet-IP communication data over short to extended ranges using the 900 MHz frequency (902-928). All devices are plug-and-play requiring no special programming tools. Using a web browser or patch cable synching, radios can be addressed to one another in the field. All WBT900-IP transceivers are shipped by default as a Client/Subscriber.

The WBT900-IP Transceiver allows the user to create a long-range, wireless BACnet-IP network with numerous Client units (up to 16) per Server transceiver.

Configuring a wireless link with the WBT900-IP requires the establishment of five elements:

1. Each radio must know whether it is to be a Server or Client.
2. The Server must know how many Clients are expecting communication with it.
3. The Server and any given Client must agree on which radio frequency channel they are using.
This can be set manually using a HyperTerminal interface and preconfigured configuration files.
4. The Client must be assigned a unique subscriber ID to specify which time division slot it will use when communicating with the Server.
5. The Server and any given Client must share a common 128-bit encryption key and Network ID.

The Server automatically scans for the best of the 12 available radio frequency channels, encrypts BACnet-IP data received from the network, and transmits it wirelessly to the correct Client. The Server is constantly monitoring the radio link and can automatically change the channel if performance is degraded due to interference. If two Server units are very close to one another, they may interfere if operating on adjacent frequency channels. Place them at least 20 feet apart or manually select non-adjacent channels for their operation. Also, the Client should be placed at least 10 feet from the Server to avoid overloading the WBT900-IP receiver.

900 MHz Channel Table

1	903.12500 MHz	7	915.62500 MHz
2	905.20833 MHz	8	917.70833 MHz
3	907.29167 MHz	9	919.79167 MHz
4	909.37500 MHz	10	921.87500 MHz
5	911.45833 MHz	11	923.95833 MHz
6	913.54167 MHz	12	926.04167 MHz

WARNING: If using AC power option, a 24 VAC isolation transformer must be used! Ensure neither of the two secondaries are bonded.

NOTE: As with any RF network, plan ahead for proper antenna selection and placement. It is the intention of Wattstopper to provide a reliable wireless communication device for existing BACnet MSTP networks. However, in some conditions, reliability is determined largely by correct antenna placement, which is the responsibility of the installer. This product is NOT TO BE USED in situations where life safety issues may arise. Wattstopper makes no claims, expressed or implied, of the product's usefulness with regard to specific applications. Determination of the product's suitability for a particular application is the sole responsibility of the purchasing parties. In any installation, ensure the devices are properly protected from the elements by installing in an appropriate enclosure. Additional surge protection devices may be necessary to protect from lightning and/or power surges.

WARNING: Extra care must be taken when attaching the antenna to the bridge unit. Finger tight is sufficient, using tools may damage the RPSMA connector if over tightened.

INSTALLATION

1. Connect BACnet-IP bus to WBT900-IP via the RJ45 Port.
2. Connect 12-24 VAC/DC power as labeled.**
3. Digital LED sequence should begin, "AIC", "ETH", "revision number".
4. AIC900-E begins searching for paired unit(s).

NOTE: For radios configured as a server, the LED channel numbers descend from 12 to 0, and reverse for client radios.

5. Verify the RF network communication with the Channel, Link Quality "LQ", RFTX, RFRX, Link, and Power LEDs.

DIP SWITCH SETTINGS

- Switch 1 Down (Away from label) Server Radio Setting
- Switch 1 Up (Towards label) Client Radio Setting
- Switch 2 (Factory Use Only) LEAVE IN UP POSITION

DIRECT PATCH CABLE PAIRING

Follow these instructions to establish a Server (Access Point) / Client (Subscriber) relationship between the WBT900-IP transceivers using the Direct Patch Cable method.

1. Place DIP Switch 1 in the down position (away from the top label) to designate the WBT900-IP as a Server/Access Point.
2. Ensure both DIP Switch 1 and 2 are in the up position (towards the top label) for each Client/Subscriber unit.
NOTE: Each Server/Access Point can be addressed to only 16 Client/Subscriber units.
3. Connect a standard patch cable via the RJ45 port between the designated Server/Access Point and the Client/Subscriber unit to be paired.
4. Power on the Client/Subscriber unit. Then, power on the Server/Access Point unit within 5 seconds.
The Channel and Link Quality LEDs will sequence and stop on the revision number. Wait 5 seconds. At this point the Server/Access Point is exchanging internal addressing information with the Client/Subscriber unit.
5. Cycle power on each unit and remove the patch cable.
6. With antennas connected and a minimum of 3 feet distance between transceivers, the Client/Subscriber links up with the Server/Access Point, indicated by a locked channel and fixed link quality on the LEDs.
7. Repeat as necessary with additional Client/Subscriber units.

WEB BROWSER PAIRING

Follow these instructions to establish a Server (Access Point) / Client (Subscriber) relationship between the WBT900-IP transceivers using the Web Browser method.

NOTE: The internal IP Address of each WBT900-IP by default is 192.168.17.17.

1. Set the laptop/PC used to configure the WBT900-IP to a static IP Address such as 192.168.17.19.
2. Connect a standard patch cable between the laptop/PC and the WBT900-IP.
3. Ensure that the desired DIP Switch setting is selected.

Refer to **DIP Switch Settings**.

4. Apply power to the WBT900-IP.
5. Open the laptop/PC web browser and enter the IP Address of the unit: 192.168.17.17
The Wattstopper splash screen opens.
6. Enter the password "password" where prompted.
The Statistics and Device Information populates with the information in the transceiver.
7. Scroll to the bottom and select the "Advanced Admin" button.
8. Under the Device Settings tab in Advanced Admin the device can be configured.

NOTE: If the device is manually configured via DIP Switches as a Server/Access Point or Client/Subscriber do not change via the web browser. This will populate based on the DIP Switch setting.

9. Enter the Client/Subscriber ID number where prompted.

NOTE: Each client must have a unique ID, not to exceed 16 per Server Access Point. If the device is a Server/Access Point, the number of subscribers on this unit's network needs to be entered. **Example:** the Number 8 is entered if the Server/Access Point is addressed to 8 Client/Subscriber units.

If desired, a user specific Network Name (32-bit HEX) and Encryption Key (128-bit HEX) can be applied following the listed example.

10. After all changes have been made, select **Apply**.
11. After applying the changes, select the **Reset Device** button.
This cycles power on the device and ensure all changes were accepted.

EMBEDDED SPECTRUM ANALYZER

Follow these instructions to utilize the embedded Spectrum Analyzer. This can be a valuable tool to evaluate the RF environment of the installation site.

NOTE: The internal IP Address of each WBT900-IP by default is 192.168.17.17.

1. Set the laptop/PC used to configure the WBT900-IP to a static IP Address, such as 192.168.17.19.
2. Connect a standard patch cable between the laptop/PC and the WBT900-IP.
3. Apply power to the WBT900-IP.
4. Connect the desired Omni-Directional or Directional antenna to the WBT900-IP.
5. Open the laptop/PC web browser and enter the IP Address of the unit: 192.168.17.17
The Wattstopper splash screen opens.
Enter the password "password" where prompted.
6. Scroll to the bottom of the page and select **Fast Spectrum Scan**.
7. Change the **Automatic Scan Interval** to the desired refresh rate.
8. Select **Scan Now** to begin analyzing the RF environment within range of the WBT900-IP.
9. Move the antenna, if directional, to scan a wider area.
10. Log out of the unit when finished, and cycle power.

For Support Information, contact Wattstopper at 800-879-8585.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

WARRANTY INFORMATION	INFORMATIONS RELATIVES À LA GARANTIE	INFORMACIÓN DE LA GARANTÍA
<p>Wattstopper warrants its products to be free of defects in materials and workmanship for a period of five (5) years. There are no obligations or liabilities on the part of Wattstopper for consequential damages arising out of, or in connection with, the use or performance of this product or other indirect damages with respect to loss of property, revenue or profit, or cost of removal, installation or reinstallation.</p>	<p>Wattstopper garantit que ses produits sont exempts de défauts de matériaux et de fabrication pour une période de cinq (5) ans. Wattstopper ne peut être tenu responsable de tout dommage consécutif causé par ou lié à l'utilisation ou à la performance de ce produit ou tout autre dommage indirect lié à la perte de propriété, de revenus, ou de profits, ou aux coûts d'enlèvement, d'installation ou de réinstallation.</p>	<p>Wattstopper garantiza que sus productos están libres de defectos en materiales y mano de obra por un período de cinco (5) años. No existen obligaciones ni responsabilidades por parte de Wattstopper por daños consecuentes que se deriven o estén relacionados con el uso o el rendimiento de este producto u otros daños indirectos con respecto a la pérdida de propiedad, renta o ganancias, o al costo de extracción, instalación o reinstalación.</p>