WATTSTOPPER

Cleaning and Disinfecting Procedures for Wattstopper Wall Switches

This document outlines the recommended procedures for cleaning and disinfecting all Wattstopper Wall Switches. These are two distinct steps:

- Cleaning removes dirt, grease, dust, and other contaminants.
- Disinfecting uses chemical agents to eliminate bacteria and other pathogens.

General Precautions

- Do not spray liquids directly onto the wall switch.
- Always use a non-abrasive lint-free cloth to avoid damaging the surface and internal components.

Step 1: Cleaning

- **Prepare the Cloth:** Lightly dampen a non-abrasive lint-free cloth with water or a mild cleaner. Ensure the cloth is not dripping—excess liquid should be squeezed out.
- **Wipe the Surface:** Gently clean the wall switch and wall plate using small circular motions. Avoid applying excessive pressure.

Step 2: Disinfecting

- **Prepare the Cloth:** Use a clean, non-abrasive lint-free cloth dampened with 70% isopropyl alcohol disinfecting solution. Ensure the cloth is not dripping—excess liquid should be squeezed out.
- **Disinfect the Surface:** Wipe the wall
- switch and wall plate gently in small circular motions. Allow time for the surface to air dry completely before use.

⚠️ Do not use any other chemical products—only 70% isopropyl alcohol disinfecting solution is approved.