Cleaning and Disinfecting LMGS-150 & EN-GS-150 Graphic Switch Touchscreen

This document outlines the recommended procedures for cleaning and disinfecting the Graphic Switch touchscreen.

- Cleaning removes dirt, grease, dust, and other contaminants.
- Disinfecting uses chemical agents to eliminate bacteria and other pathogens.

General Precautions

- The touchscreen is not water-resistant, excess moisture may damage the device
- Do not spray liquids directly onto the touchscreen.
- Always use a non-abrasive cloth to avoid damaging the surface.
- Lock the screen before cleaning to prevent accidental activation of loads.

Cleaning

- Lock the Screen: Navigate to the Settings menu via the Hamburger icon and tap “Lock Screen” to prevent unintended operation during cleaning.
- Prepare the Cloth: Lightly dampen a non-abrasive cloth with water or a mild cleaner. Ensure the cloth is not dripping—excess liquid should be squeezed out.
- Wipe the Surface: Gently clean the touchscreen using small circular motions. Avoid applying excessive pressure.

Disinfecting

- Lock the Screen: As with cleaning, go to the Settings menu and tap “Lock Screen” to disable touch functionality during disinfecting.
- Prepare the Cloth: Use a clean, non-abrasive cloth dampened with 70% isopropyl alcohol. Again, ensure the cloth is not overly wet.
- Disinfect the Surface: Wipe the touchscreen gently in small circular motions.

⚠ Do not use any other chemical products only 70% isopropyl alcohol is recommended

WATTSTOPPER, 2234 Rutherford Rd, Carlsbad, CA 92008 . Tel: (760) 804 9701 . www.legrand.us/wattstopper

WATTSTOPPER®

legrand®