



Typical DLM Simple Integration: Dry Contact with Momentary Up/Down/Stop Control or Two Set Points

USA Phone: 850-208-3417		Solarfactive	
Canada Phone: 416-421-3800		sfsupport@legrand.us	
Title			
Solarfactive AC Drive Shade Block with Basic Dry Contact DLM Integration			
Scale	Drawing#	Date	Rev.
None	200-101	06-18-2018	A