

Overview

Vantage's Equinox 73 retrofit install kit is designed to mount the Equinox 73 Touchscreen directly to sheetrock without the added cost of the bezel, saving time and money. For new construction installations, please see *Equinox 73 LCD Standard_EQ73ST-INSTALL_install_IS-0545.pdf* instruction sheet.

Specifications

DESCRIPTION	SPECIFICATION
retrofit (insert) dimensions - cut sheetrock opening to this size	6. 3/8" x 4. 3/8" 162mm x 111mm

Installation


Installation of Vantage products should be performed or supervised by a *Certified Vantage Installer*. Prepare the wall opening. The recommended mounting height is six inches above that of a typical keypad station or approximately 50" to 58" from the floor to the bottom of the Equinox 73 Touchscreen. However, it may be installed at any height fitting specific custom installation requirements.

NOTE: The installer must provide an Ethernet RJ-45 connection wire. Ethernet cable should be CAT5e or better with POE or POE+ support.

Easy Installation Steps

- CUT:** Cut a *precise rectangular* hole in the sheetrock - 6. 3/8" wide by 4. 3/8" high. The hole should be **very clean-cut, exact** and **must be level**. Adjustable tolerances are extremely small and extra care should be taken in cutting the hole out. Adjustment to the inside ring (see *figure 1a*.) is limited or the edge of the install bracket will show.
 - Fine tune a small amount by tilting the ring slightly to level screen - see *figure 1a* below; illustration is exaggerated.


- INSERT BRACKET / BEND WINGS:** Place bracket into the hole and *carefully bend* the two sides back around to meet the back of the sheetrock as illustrated. Avoid over bending the wings. Do not screw sides in until step 4.



- SECURE INSIDE RING:** Secure inside ring with the two screws provided.



- FINAL SCREWS:** Secure completed assembly using the four self tapping screws angled as illustrated - two screws on each side. **DO NOT OVER TIGHTEN!**



- INSTALL EQ73:** The retrofit bracket is now ready to receive an Equinox 73 touchscreen by pressing straight back on both sides at the same time until locked and secure.

