



Note:
Shall be mounted
per instructions.

Note:

① A voltage barrier (HBAR-x) must be installed to separate line voltage from low voltage.

Watt Stopper/Legrand
800-879-8585

Title
Wiring from LCO-203 to
LI Panels with Automation

Scale None	Drawing# 60-925-1	Date 08/10/07	Rev. 1
---------------	----------------------	------------------	-----------