


Two BZ-200 Power Packs and Sensor(s)



* At least 3 Sensors can be powered by the power pack. See Sensor data sheet.

** BZ-200 Power Pack must be grounded to ensure signal integrity, not for safety ground.

Watt Stopper/Legrand 800-879-8585			
Title Two BZ-200 Power Packs and Sensor(s)			
Scale	Drawing#	Date	Rev.
None	57-003-8	08/06/15	0