

## DEVICES ARE PRESET FOR PLUG n' GO™ OPERATION, ADJUSTMENT IS OPTIONAL.

Sequence of Operation: In this configuration The LMRC-101 defaults to manual-on/automatic off. Maximum of 4 room controllers, controlling up to 8 loads and up to 24 communicating devices per DLM local network. For full operational details, adjustments and more features of the product, see the DLM System Installation Guide at www.wattstopper.com

## *WattStopper*® 800-879-8585

LMRC-101 Single Relay Wiring Diagram

Scale	Drawing#	Date	Re
None	90-111	10/14/10	2