

DEVICES ARE PRESET FOR PLUG n' GOTM OPERATION, ADJUSTMENT IS OPTIONAL.

Sequence of Operation: In this configuration The LMRC-102 defaults to multi-level automatic-on/automatic off. Load (a) turns on automatically and load (b) defaults to manual—on control; both loads turn automatically off. Maximum of 4 room controllers, controlling up to 8 loads and up to 24 communicating devices per DLM local network. The For full operational details, adjustments and more features of the product, see the DLM System Installation Guide at www.wattstopper.com

<i>WattStopper</i>
800-879-8585

LMRC-102 Dual Relay Wiring Diagram

Scale	Drawing#	Date
None	90-121	10/14/10

Rev.

2