INSTRUCTION/INSTALLATION SHEET
inQuire™ 1000 Intercom Door Chime

301 Fulling Mill Road, Suite G
Middletown, PA 17057
Phone (800) 321-2343 / Fax (717) 702-2546
www.onqlegrand.com

IS-0372 REV. O

1. Introduction

The On-Q /Legrand inQuire™ 1000 Intercom Door Chime, PN F7601 (see ***Figure 1***), is a component that installs as an add-on to the inQuire™ 1000 Intercom Module that enables a chime to be heard at each intercom location throughout the house.



Figure 1

2. Description

The Door Chime attaches to the rear of the inQuire™ 1000 Intercom Module in the enclosure (see ***Figure 2***). When a visitor presses the door chime button on the inQuire™ 1000 Door Unit, a chime is heard on each inQuire™ 1000 system device (eg. Room Unit) that contains a speaker.

3. Installation

Installation of the inQuire™ 1000 Door Chime can occur at any time, as long as the inQuire™ 1000 Intercom Module in the enclosure is available.

NOTE: If the inQuire™ 1000 Intercom System is already installed and functional, you will need to first remove power from the Intercom Module before attaching the Door Chime to the rear of the Module.

A. Place the Door Chime board on the rear of the Intercom Module so that the two mounting holes on the Door Chime are seated over the threaded studs on the rear of the Intercom Module.

B. Ensure that the Door Chime's pin array lines up with the socket on the rear of the Intercom Module and apply slight pressure to seat the Door Chime.

C. Use the included washers and hex nuts to secure the Door Chime to the Intercom Module.

D. If the user wishes to hear the doorchime play through the Door Unit when the button is pressed, remove the shunt from Jumper #2 on the rear of the Intercom Module.

E. Re-apply power to the Intercom Module and have someone press the Door Chime button on a Door Unit. You should hear the chime at any inQuire™ 1000 Intercom system location.



Figure 2

Rear of Intercom Module

©Copyright 2006 by On-Q/Legrand All Rights Reserved.