Prerequisites:

1. Fully configure the Player Portfolio System
   - *Setup & functional via Nuvo Player app*
2. Download the driver: (*You will be redirected to the RTI Dealer Site)*
   - *Navigate to: Driver Store*
   - *Search by Manufacturer: **"NuVo"***
   - *Select: **"Nuvo Wireless Audio System"***
3. Unzip to: *My Documents/Integration Designer/Control Drivers*

Step 1: Add the driver to the workspace

1. Select: The first room with a Nuvo Zone
1. Right-Click: "Add New"
2. Select: Drivers>***NuVo Wireless***
3. Click: Next
4. Click: Add Device
   - *Repeat for all other rooms that are Nuvo Zone*
5. Click: "Close" When done.

Step 2: Configure the driver

1. Select: Drivers>***NuVo Wireless***>Driver Properties
2. Enter the **EXACT** name of Player 1 from the Nuvo Player App in the Player 1 Name field of the Players configuration menu.
   - *Repeat the above step for each Player in the system.*

NOTE: The names must be spelled exactly the same including any spaces placed at the end of a device name by your mobile device's auto-fill.

"Music Player" page(s) will be created and auto-programmed for each controller.

Step 3: Add page links, buttons, macros and variables as needed

1. Select: Macro Steps>Sources>***NuVo Wireless*** for a complete list of all the commands available to set volumes, provide transport controls, group zones etc...