BZ–250 Power Pack and Sensor with MANUAL ON



* At least 3 Sensors can be powered by the power pack.
See Sensor data sheet.

** BZ–250 Power Pack must be grounded to ensure signal integrity, not for safety ground.

Watt Stopper/Legrand 800–879–8585			
Title BZ–250 Power Pack and Sensor with MANUAL ON			
Scale None	Drawing# 57–003–12	Date 08/06/15	Rev. 0