



DEVICES ARE PRESET FOR PLUG n' GO™ OPERATION,  
ADJUSTMENT IS OPTIONAL.  
Sequence of Operation: In this configuration The LMRC-101 defaults  
to manual-on/automatic off. Maximum of 4 room controllers,  
controlling up to 8 loads and up to 24 communicating devices per  
DLM local network. For full operational details, adjustments and more  
features of the product, see the DLM System Installation Guide at  
[www.wattstopper.com](http://www.wattstopper.com)

<b>WattStopper®</b> 800-879-8585			
Title LMRC-101 Single Relay Wiring Diagram			
Scale None	Drawing# 90-111	Date 10/14/10	Rev. 2