



DEVICES ARE PRESET FOR PLUG n' GO™ OPERATION, ADJUSTMENT IS OPTIONAL.

Sequence of Operation: In this configuration The LMRC-102 defaults to multi-level automatic-on/automatic off. Load (a) turns on automatically and load (b) defaults to manual-on control; both loads turn automatically off. Maximum of 4 room controllers, controlling up to 8 loads and up to 24 communicating devices per DLM local network. The For full operational details, adjustments and more features of the product, see the DLM System Installation Guide at [www.wattstopper.com](http://www.wattstopper.com)

<b>WattStopper®</b> 800-879-8585			
Title LMRC-102 Dual Relay Wiring Diagram			
Scale None	Drawing# 90-121	Date 10/14/10	Rev. 2