



EXSP Expansion Splice Kit




- **Material:** Aluminum Alloy 6063-T6
- **Finish:** Plain
- **Height (H):** Tray height: 4", 5", 6", 7"



Installation:

- Screw heads should be on the inside and nuts on the outside of the cable tray.
- Flanged hex nuts should be used in round holes. Tighten flanged hex nuts to 17-23 ft-lbs.
- Locking hex nuts and flat washers should be used in slotted holes. Tighten locking hex nuts fully, then back off 1/2 turn.
- Refer to NEMA BI-50016 / NEMA VE2 to determine gap setting and expansion joint spacing.

PRODUCT CODE	FASTENER OPTIONS
EXSP	S6
CATALOG NUMBERING EXAMPLE:	
H / Material	Fasteners
4 A -	EXSP - S 6

The  symbol indicates that a bonding jumper is required on one side of the tray.