



ORTRONICS®

125 EUGENE O'NEILL DRIVE
NEW LONDON, CT 06320
TEL: 860-445-3800
FAX: 860-405-2990

TITLE

FIBER/COPPER PATCH PANEL INSTRUCTION SHEET

FIBER ROUTING:

1. MAINTAIN A MINIMUM BEND RADIUS
OF 10 TIMES THE OUTSIDE DIAMETER
OF THE FIBER JACKET.
(SEE FIGURE 1).




FIGURE 1

NOTE: KEEP FIBER AND COPPER CABLES
SEPARATED (SEE FIGURE 1).

COPPER WIRE ROUTING:

1. PULL CABLE THROUGH BEZEL
WHERE THE MODULE WILL BE LOCATED.
PLACE MODULE WITH FRONT FACE
AGAINST THE NEAREST SUITABLE
TERMINATION LOCATION (FIGURE 2).
TERMINATE PER WIRING AND CABLING
INSTRUCTIONS, THEN FLIP MODULE OVER
AND SNAP INTO PLACE IN BEZEL.
REPEAT FOR ALL MODULES.
2. MAINTAIN A MINIMUM BEND RADIUS
OF 4 TIMES THE OUTSIDE DIAMETER
OF THE CABLE.




FIGURE 2

CAD: I:\716\011001

INSTRUCTION SHEET #	REV.	ECN #	SHEET	DWN.BY:	DATE	CHK.BY:	DATE	APP.BY:	DATE
71601100			1 of 1	WATROUS	08/25/00				